

## Sensingtek Product Set-up Menu

V1.1





#### software:

ITRI NuSens RF24 Engineering tool

### Tool or Interface:

(1)Coordinator USB: Through USB

(2)Coordinator Ethernet: Through Ethernet

(3)DI · AI · T&H · K-TYPE: Through RF With Coordinator

**PANID** RF Channel

Modbus TCP **UDP UART** 

Sample rate:


Node Setup Frequency

**Need to Follow** 


Coordinator

## Product Setup -Coordinator USB(1)


#### Step1 Open ITRI NuSens RF24 Engineering tool



## Product Setup -Coordinator USB(2)




# Product Setup -Coordinator USB(3)




## Product Setup -Coordinator Ethernet(1)

Step1 Open ITRI NuSens RF24 Engineering tool




# Product Setup -Coordinator Ethernet(2)




## Product Setup -Coordinator Ethernetsing IEN

Network Parameter (1)
Step1 Open ITRI NuSens RF24 Engineering tool



# Product Setup -Coordinator Ethernet sensing TEN Network Parameter(2)






## Product Setup -DI \ AI \ T&H \ K-TYPE(1)

- Step1
   Link Coordinator on Computer
- Step2
- 1. T&H: Hold The Function Key to Switch on The Power, till Green LED "ON". And Press The Function Key Again Until The Blue LED Light and Green LED Off, Get Into The Setup Mode.
- 2. DI AI K-TYPE: Plug DC Power then Red and Green LED Will Flash In The Same time Within 5 Sec, And Hold The Function Key to Switch on The Power, till Green LED "ON". And Press The Function Key Again Until The Blue LED Light and Green LED Off, Get Into The Setup Mode.

## Product Setup -DI 、 AI 、 T&H 、 K-TYPE(2)

#### Step3 Open ITRI NuSens RF24 Engineering tool








## Product Setup -DI \ AI \ T&H \ K-TYPE(3)

💕 ITRI NuSens RF24 Engineer	ing Tool - Version 1.1.1b			X	
Node RF					
⊢Interface-				_	
© RS-232	met Conn	ect	Disconnect		
-Parameters-				I	
■ □ ID:	(0~65535)				
PAN ID:	(0~65535)				
Sample Rate : □ Depe	end on Coordinator Sec/Tir	me			
Model:	(0~255)				
RF Power: 0	dBm		Read		
RF Channel:	(2400 MHz)				
	, ,	_	Save S	ep6	
			Pro	ess "F	Read
Transceiver Test					
200			Test		
Transmit: 300	Fail:O Packets (0%)		1630		
		0%			



### Product Setup -DI \ AI \ T&H \ K-TYPE(5)




# Product Setup –Al Detect Range Sensing TEK And Jumper Setup


Step1 Open The Case



Step2 0~1V,0~5V,0~10V Jumper Setup 0-20mA,




### 0-20mA,4-20mA Jumper Setup





### **Product Setup -K TYPE Calibration**



- The Accuracy is ±3°C
   Before K type Sensor
   Calibration, After Calibrate
   Process can be Accuracy
   ±1°C.
- Press Connect Bottom And Follow System Instruction.
- Base on Four Standard
   Temperature to Calibrate
   Node . System Will Display
   Relate Value (Before and
   After Calibration).
- The Calibration Parameter
  Will be Save Into The Node
  Automatically, Meanwhile
  Node Output Value Will
  Follow New Parameter.



## **Setup System**

#### Software:

- (1)Coordinator Setup: NuSens Engineering tool (RF Parameter and Network Parameter Setup)
- (2)DI · AI · T&H · K-TYPE Setup : NuSens Engineering tool

### **Tool or Interface:**

- (1)Coordinator USB: Through USB
- (2)Coordinator Ethernet: Through Ethernet
- (3)DI \ AI \ T&H \ K-TYPE : Through RF with Coordinator

### **Backend Software:**

- (1)NuSens Server (UDP, UART)
- (2) Another Software (Modbus TCP)




## **Setup System Flow**

**Confirm Customer Requirement Monitor Program Selection Node type Selection Coordinator type Selection Monitor Program Setup Node Setup Coordinator Setup System Setup Completed** 

# Setup System - NuSens Server UDP or UART(1)

### •Step1

- (1)Coordinator RS-232:PCNeed Install USB Driver" CP210xVCPInstaller.exe", And use NuSens Engineering tool Setup Coordinator Parameter And IP
- (2)Coordinator UDP: Use NuSens Engineering tool Setup Coordinator Parameter And IP



# Setup System - NuSens Server UDP or IEK UART(2)

Step2 Install NuSens WSN Server




Step3 Send The200XXXXXAppREG.CWB to martin.lee@itri.org.tw

Step4 Execute 200XXXXXAppREG # 20080729AppREG reg




Setup System -NuSens Server UDP or IEK



Setup System - NuSens Server UDP or IEK UART(3)



Setup System - NuSens Server UDP of UART(4)






## **Setup System - Modbus**

### •Step1

Coordinator TCP:Use NuSens Engineering tool Setup Coordinator Parameter And IP



#### **FCC Compliance and Advisory Statement**

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, according to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

- 1. Reorient the receiving antenna.
- 2.Increase the separation between the equipment and receiver.
- Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- 4. Consult the dealer or an experienced radio/TV technician for help.

Any special accessories needed for compliance must be specified in the instruction manual.

**Warning:** A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used. Use only shielded cables to connect I/O devices to this equipment.

**CAUSION:** Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.